




great things happen in a chair



view is back of
armless chair

USER GUIDE: LS4B/LS4W 4u mesh & 4u groove adjustable lumbar support (optional)

1 lumbar position adjustment - From the seated position, use a hand to make adjustments by engaging the small, black lumbar adjustment lever. Slide the lever up to move the lumbar support up. Slide the lever down to move the adjustable lumbar support down.

slide up = lumbar up

slide down = lumbar down



Contract Holder

contract #: GS-28F-005CA

contractor: VIA INC